

1. IMPORTANT: READ ALL INSTRUCTIONS BEFORE PERFORMING TASK

2. Place Mounting Plate on concrete floor in desired location. Ensure that the set screws on the Mounting Plate are not touching the floor at this point (Depending on the size of the Mounting Plate it may have four (4) or more set screws). If eye-bolts are provided, these may be used in the force plate mounting locations to make lifting and moving of the Mounting Plate easier.

3. Assemble force plate to Mounting Plate using the provided bolts (3/8 - 16 UNC or M8 - 1.25) and washers in the outer corner holes.

4. Level force plate using the outer accessible set screws (use a cross level on force plate top if necessary). Make sure that the Mounting Plate is lifted from the floor at least 1/16 - 1/8 inches (2 - 3 mm) to allow room for the construction adhesive. If the force plate is mounted in a pit, which does not provide easy access to the set screws or for nonconductive plates, the Mounting Plate can be leveled first. However, make sure that the top of the force plate is flush with the floor before proceeding further.

5. Mark outer perimeter of Mounting Plate on floor.

6. Remove the bolts from Step 3, separating the force plate from the Mounting Plate. Leave the Mounting Plate in its position.

7. Adjust any unadjusted set screws in the middle of the Mounting Plate so that they just touch the floor. When working with large Mounting Plates make sure that the Mounting Plate has not sagged in the middle. If necessary make further adjustments to the central set screws.

8. Remove the Mounting Plate. Make sure that the set screw adjustments do not change.

9. Prepare the construction adhesive in the caulk gun as directed on the product. The working life of the adhesive is 15 minutes.

10. Using the construction adhesive, lay out a grid within the marked area for the mounting plate. Keep the adhesive bead width to 1/4 - 3/8 inch. Allocate the adhesive equally over the entire grid.

11. Carefully relocate the Mounting Plate back to the marked area. Press down firmly to make sure the set screws are touching the floor and the plate is level.

12. Allow the construction adhesive to cure for 24 hours before attaching the force plate to Mounting Plate.

